



## Instructions for SoyLite™ Wax Melter

### Use at your own risk

- Always wear gloves and safety glasses to avoid burning your skin from hot wax
- Never leave the melter unattended while in use
- Always have a fire extinguisher near by when in use
- Always have a thermometer handy when melting wax to prevent burning of the wax
- Never let the wax heat up past 190 degrees. The ideal temperature is 180 degrees
- Never drain 90% or more of the wax, this will cause overheating. Make sure there is always an ample amount of wax in the melter at all times when heating
- When not in use always unplug the melter
- Never allow a minor use the melter without supervision. An adult, 21 and over, should always be present when operating the melter.

### Important Cord and Plug Information

A short power supply cord (or cord set) is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. DO NOT USE WITH AN EXTENSION CORD.

Do not allow the cord to run underneath or around the unit. The magnetic cord may not detach easily if the cord is positioned in this fashion.

Connect the power supply cord to a polarized outlet only. As a safety feature, this appliance has a polarized plug (one blade is wider than the other). This plug will only fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.