

the Kodak Carousel Transvue 140 slide tray


Holds 140 slides in 2 x 2-inch cardboard or thin plastic mounts (not glass or metal mounts) *up to 1/16 inch thick*. Since this tray was designed to hold as many slides as possible, the slide compartments in the tray are quite narrow. For this reason, your slide mounts should be in good condition. Mounts which are warped or bent may fail to drop from the tray into the projector. (If this happens, straighten the mount with your fingers or place the slide in a new mount, such as a KODAK READY-MOUNT.)

Important: Clip off all mount corners that are frayed. Do not use slides mounted with loose or sticky tape.

Loading tray

Check the bottom of the tray to make sure that the INDEX HOLE is opposite the INDEX NOTCH, as shown. If it isn't, slide the LATCH in the direction shown by the arrow and turn the bottom plate until the index hole points to the index notch. Then turn the tray over. Turn the lock ring in the direction of the arrow marked UNLOCK; then lift off the ring. Insert a slide into each slot in the tray, with the top of the picture down. The printed border or trademark side of each cardboard mount, or the emulsion (dull) surface of the slide, should face the lower-numbered slides. For example, the bordered, trademark (or emulsion) side of slide No. 2 should face toward the first slide; the third slide should face toward No. 2, etc. Replace the lock ring, turning it in the direction of the arrow marked LOCK until the ring is secure on the tray.

INDEX NOTCH
INDEX HOLE




Placing tray on projector

Place the loaded slide tray on the projector so that the hole in the center of the tray fits over the center post on the top of the projector; then turn the tray slowly in a clockwise direction until the tray index bar is opposite the gate index on the projector. The tray will drop down into operating position on the top of the projector. If the tray doesn't drop easily into place, check the alignment of the index hole and the index notch as described under "Loading tray." (Be sure that the lock ring is secure *before* you turn the tray over!) NOTE: The tray drops down farther during the first change cycle.

TRAY INDEX BAR
GATE INDEX

To order additional index cards (up to 25), order part number 194280 from
Eastman Kodak Company
Central Parts Service
800 Lee Road
Rochester, New York 14650



MADE IN U.S.A. BY **EASTMAN KODAK COMPANY** • ROCHESTER, N.Y. 14650

Consumer Markets Division

T.M.: Kodak, Carousel, Transvue, Ready-Mount