



Google Home Hub Instructions

What you will need:

1. A mobile device, Smart phone, tablet, etc.
2. Access to a WiFi network.
3. Latest Google Home App downloaded on your device.
 Visit either the Google Play Store or the IOS App Store to download if you do not already have the Google Home App
4. A Google Account.

To Get Started:

1. Plug the power cable into your Google Home Hub device.
2. Plug the power adapter into a wall outlet.
3. Connect your mobile device to the Wi-Fi network that you'll use for your speaker or display.
4. On your phone or tablet, open the Google Home app Google Home app.
5. Follow the steps listed.
 - a. If you don't see the steps to set up your device:
 - i. On the Google Home app's home screen, tap Add  > Set up device  > Set up new devices.
 - ii. Follow the remaining steps.
6. Start talking with your new Google Assistant.

To Fix Issues During Set Up.

If You Can't see the mini speaker in the Google Home app

Restart your device

1. Unplug your device.
2. Wait 10 seconds, then plug it back in.

Restart the Home app

1. Close the Home app Google Home app.
2. Open the Home app Google Home app.

If Setup freezes or can't finish

1. Restart your device
2. Unplug your device.
3. Wait 10 seconds, then plug it back in.

**The Google Home Hub must be factory reset
before returning**

Resetting will:

- * Erase all your personal data
- * Reset all settings and return the google home mini to a state ready for initial setup.

Instructions for factory reset from device:

1. Press and hold the factory volume-up and volume-down buttons together for about 10 seconds.
2. A warning will appear on the screen that the device will be reset and you will hear your Google Assistant confirm that it's resetting the device.