



Google Home Mini Instructions

What you will need:

1. A mobile device, Smart phone, tablet, etc.
2. Access to a WiFi network.
3. Latest Google Home App downloaded on your device.
 Visit either the Google Play Store or the IOS App Store to download if you do not already have the Google Home App
4. A Google Account.

To Get Started:

1. Plug the power cable into your Google Home Mini device.
2. Plug the power adapter into a wall outlet.
3. Connect your mobile device to the Wi-Fi network that you'll use for your speaker or display.
4. On your phone or tablet, open the Google Home app Google Home app.
5. Follow the steps listed.
 - a. If you don't see the steps to set up your device:
 - i. On the Google Home app's home screen, tap Add  > Set up device  > Set up new devices.
 - ii. Follow the remaining steps.
6. Start talking with your new Google Assistant.

To Fix Issues During Set Up.

If You Can't see the mini speaker in the Google Home app

Restart your device

1. Unplug your device.
2. Wait 10 seconds, then plug it back in.

Restart the Home app

1. Close the Home app Google Home app. Learn how to close apps.
2. Open the Home app Google Home app.

If Setup freezes or can't finish

1. Restart your device
2. Unplug your device.
3. Wait 10 seconds, then plug it back in.

**The Google Home Mini must be factory reset
before returning**

Resetting will:

- * Erase all your personal data
- * Reset all settings and return the google home mini to a state ready for initial setup.

Instructions for factory reset from device:

1. Press and hold the factory reset button located below the power cord on the bottom of Mini for about 15 seconds (look for a circle etched into the base).
2. You'll hear your Google Assistant confirm that it's resetting Mini.